Date: 15 JUN 2020 Tel: +65 68851345 Fax: +65 67732912

Client's Ref: Email: Randy.CHIN@tuv-sud-psb.sg

**Note:** This report is issued subject to the Testing and Certification Regulations of the TÜV SÜD Group and the General Terms and Conditions of Business of TÜV SÜD PSB Pte Ltd. In addition, this report is governed by the terms set out within this report.



**PSB** Singapore

Add value. Inspire trust.

#### **SUBJECT**

Antibacterial Activity Evaluation

#### **CLIENT**

Magna International Pte Ltd 10H Enterprise Road Singapore 629834

### SAMPLE SUBMISSION DATE/ TEST DATE

02 Jun 2020 / 04 Jun 2020

### **DESCRIPTION OF SAMPLE**

One sample labelled as follows was submitted.

Product: Legionella-X Viral Kleen fortified with Silver and Copper Nanoparticles, for disinfecting face shield, goggles and all types plastic shield. Sample has been diluted with 1:25 parts of tap water

### **METHOD OF TEST**

BS EN 1040: 2005

"Chemical disinfectants and antiseptics - Quantitative suspension test for the evaluation of basic bactericidal activity of chemical disinfectants and antiseptics - Test method and requirements (Phase 1)".

The test microorganisms used were:

Pseudomonas aeruginosa (ATCC 15442) Staphylococcus aureus (ATCC 6538)

Dilution tested: Neat Contact time: 5 minutes

Neutralization method: DE Broth Neutralization

Test temperature: 20±1°C Incubation temperature: 36±1°C



Laboratory: TÜV SÜD PSB Pte. Ltd. No.1 Science Park Drive Singapore 118221

Phone: +65-6885 1333 Fax: +65-6776 8670 E-mail: enquiries@tuv-sud-psb.sg www.tuv-sud-psb.sg Co. Reg: 199002667R

Regional Head Office: TÜV SÜD Asia Pacific Pte. Ltd. 1 Science Park Drive, #02-01 Singapore 118221 TÜV®

15 JUN 2020



# **RESULTS**

Product : Legionella-X Viral Kleen fortified with Silver and Copper Nanoparticles, for disinfecting face shield, goggles and all types plastic shield.

Sample has been diluted with 1:25 parts of tap water.

### Validation and controls

Controls	Validation Suspension (Nv <sub>0</sub> )	30 <nv<sub>0&lt;160 (Pass / Fail)</nv<sub>	Experimental Condition control (A)	Neutralizer control (B)	Method Validation (C) Product Concentration: Neat	B and C ≥ 0.5 x Nv <sub>0</sub> (Pass / Fail)
Pseudomonas aeruginosa (ATCC 15442)	79	Pass	N.A.	75	90	Pass

Test Microorganism : Pseudomonas aeruginosa (ATCC 15442)

Contact Time / Concentration	Initial Count of Test Microorganism per ml of Test Mixture		Count of Surviving Test Microorganism per ml		Log Reduction	Percentage Kill of
	CFU per ml	Log <sub>10</sub>	CFU per ml	Log <sub>10</sub>		Test Microorganism
5 minutes		/ 01				
Neat	23 000 000	7.36	Less than 10	Less than 1	More than 6.36	More than 99.99995

15 JUN 2020



# RESULTS (cont'd)

: Legionella-X Viral Kleen fortified with Silver and Copper Nanoparticles, for disinfecting face shield, goggles and all types plastic shield. Sample has been diluted with 1:25 parts of tap water. Product

### Validation and controls

Controls	Validation Suspension (Nv <sub>0</sub> )	30 <nv<sub>0&lt;160 (Pass / Fail)</nv<sub>	Experimental Condition control (A)	Neutralizer control (B)	Method Validation (C) Product Concentration: Neat	B and C ≥0.5 x Nv <sub>0</sub> (Pass / Fail)
Staphylococcus aureus (ATCC 6538)	38	Pass	N.A.	34	38	Pass

Staphylococcus aureus (ATCC 6538) Test Microorganism

Contact Time /	Initial Count of Test Microorganism per ml of Test Mixture		Count of Surviving Test Microorganism per ml		Log Reduction	Percentage Kill of
Concentration	CFU per ml	Log <sub>10</sub>	CFU per ml Log <sub>10</sub>			Test Microorganism
5 minutes		20				
Neat	20 000 000	7.30	Less than 10	Less than 1	More than 6.30	More than 99.99995

15 JUN 2020



#### Remarks:

The product shall be deemed to have passed the test if it demonstrates a **5 Log reduction or more** (at least >99.999% kill) in viability within 5 minutes or less under the conditions defined by this test when the test organisms are *Pseudomonas aeruginosa* and *Staphylococcus aureus*.

This test method evaluates the basic bactericidal activity of chemical disinfectants with no specific application. It does not evaluate the activity of a product for an intended use. More specific test methods are used for further assessment of the efficacy of chemical disinfectants and antiseptics for a defined purpose.

The above test results relate to the sample as received.



15 JUN 2020



Please note that this Report is issued under the following terms:

- 1. This report applies to the sample of the specific product/equipment given at the time of its testing/calibration. The results are not used to indicate or imply that they are applicable to other similar items. In addition, such results must not be used to indicate or imply that TÜV SÜD PSB approves, recommends or endorses the manufacturer, supplier or user of such product/equipment, or that TÜV SÜD PSB in any way "guarantees" the later performance of the product/equipment. Unless otherwise stated in this report, no tests were conducted to determine long term effects of using the specific product/equipment.
- 2. The sample/s mentioned in this report is/are submitted/supplied/manufactured by the Client. TÜV SÜD PSB therefore assumes no responsibility for the accuracy of information on the brand name, model number, origin of manufacture, consignment or any information supplied.
- 3. Nothing in this report shall be interpreted to mean that TÜV SÜD PSB has verified or ascertained any endorsement or marks from any other testing authority or bodies that may be found on that sample.
- 4. This report shall not be reproduced wholly or in parts and no reference shall be made by the Client to TÜV SÜD PSB or to the report or results furnished by TÜV SÜD PSB in any advertisements or sales promotion.
- 5. Unless otherwise stated, the tests were carried out in TÜV SÜD PSB Pte Ltd, No.1 Science Park Drive Singapore 118221.

